



# Installation instructions



AN-7700BTG / AN-7700BZG / AN-7700ORB / AN-7700BKORB



**1** Disassemble parts prior to installation.



**2** Reassemble as shown above.