

# Maintenance

## Replacing the Light Bulbs

**!** **IMPORTANT:**  
**ALWAYS SWITCH OFF THE ELECTRICITY SUPPLY AT THE MAIN PANEL BEFORE CARRYING OUT ANY OPERATION ON THE APPLIANCE.**

This range hood uses halogen bulbs: 20 W 12 V type G4.

- 1** Make sure the range hood is unplugged or turn OFF breaker.
- 2** Place a flat-head screwdriver between light cover and housing to remove cover.
- 3** Gently pull defective bulb straight out and discard.

**!** **CAUTION: BULB MAY BE HOT, PLEASE TAKE OUT THE BULB WHEN THE BULB IS COMPLETELY COOL!**

- 4** Wear a cotton glove or use a cloth to handle the replacement bulb.  
DO NOT handle with bare fingers as this may shorten the life of the bulb.  
Push gently but securely into light socket.
- NOTE: DO NOT push too hard as bulb “legs” can break off.**

- 5** Replace light cover.
- 6** Turn ON breaker and range hood to test for operation.

